



- Monitoring Well without Soil Samples
- Monitoring Well with Soil Samples
- Grab Groundwater Sample
- Soil Sample
- Soil and Grab Groundwater Sample

Former Underground Storage Tank ("UST"), Above Ground Storage Tank ("AST"), Oil / Water Separator ("OWS"), Washrack, Building, or Other Location Addressed by Risk Management Plan ("RMP

Property Subject to Transfer to Oakland Base Reuse Authority ("OBRA") by Economic Development Conveyance ("EDC") ("RMP Implementation Area")

Boundary of Oakland Army Base

- All locations are approximate.
- OBRA boundary for Gateway Development based on Port of Oakland map entitled "Oakland Army Base Approximate Acreages for Traffic Analysis Possible Future Development", dated 21 August 2000.
- 3. Basemap taken from IT Corporation "OARB Site Map", dated 17 February
- Benzidine concentration shown in milligrams per kilogram ("mg/kg").



Erler Kalinowski,

Former Used Oil Tank 21 Benzidine at

Oakland Army Base September 2002 EKI A10063.00 Oakland, CA

Figure 8